

Musical

Plant Saver

Houseplant Moisture Monitor

Here's how to use your new *Plant Saver* to help keep your houseplants **Green** and Growing.

Remove the wire wrapped around the *Plant Saver* probes before use. Insert probes into the soil of your houseplant to a depth of about 2". For plants with higher moisture requirements, insert *Plant Saver* to a shallower depth. When the plant needs water, *Plant Saver's* music will play.

When you have watered your plant, the music will not stop immediately. It will continue playing until the end of the song, then stop. *Plant Saver* will play at intervals of 2-4 minutes whenever your plant needs water. You can forget about over watering and under watering, because *Plant Saver* continuously monitors the moisture level in the soil, and only plays when the soil is dry around the probes.

If you have a lot of plants, you don't need a *Plant Saver* in each one. Everyone has one plant that gets dry before the others. Put *Plant Saver* in that plant, and water them all when you hear the music.

Plant Saver uses a small, long-life battery. Under normal conditions it should last several years. Should you need to replace it, simply pop the top off of the unit, and slide the old battery out. Batteries are available from Phenix Controls Inc., or they may be purchased wherever small watch-type batteries are sold.

Over [30 different tunes](#) are available from your retailer or from Phenix Controls. For a complete list of available tunes and an order form, please contact us at the address below.

Plant Corp
1619 South Minnie Street
Santa Ana, CA 92707
(714) 547-4316
PlantCorp.com